KitchenAid

CABINET PARTS

REFRIGERATOR

For Model: 4KSRF36DTX1



1		Cabinet (Not A Serviceable Part)
2	1112019	Leveler, Front (2)
3	1113249	Retainer (2)
4	1112023	Roller, Front & Rear (4)
5	1112695	Leveler, Adjustable (2)
6	1112936	Adjusting Rod (2)
7	1113250	Sleeve, Retainer (2)
8	1112937	Bushing, Rod (2)
9	488115	Screw, 10-32 x 5/8
	489266	Screw (Repair)
10	1112939	Hole Plug, Leveler
11	1112849	Cap, Grommet
12	1112970	Grommet, Water Tube
13	1113122	Grommet, Wiring
14	1112769	Wiring Harness, Cabinet
15	1112848	Drain Fitting
16		Gap, Cover Assembly (Top)
	1113215	Left Side
	1113214	Right Side
17	1112906	Shoulder Screw
18		Hinge (Top)
	1112901	Left Side
	1112912	Right Side
19	1112988	Shim, Hinge Top (4)
20	1112805	Guard, Wiring
21	1112907	Door Closer, Fixed Cam
22	487818	Screw, 8-32 x 5/16
23	1112992	Door Closer Assembly (2)
24		Bracket, Door Closer
	1112947	Left Side
	1112948	Right Side
25	486194	Screw, 8 x 1/2
	488908	Screw (Repair)
26	1112973	Tap Plate, Hinge Butt (2)
27	1113227	Fastener (3)
28		Gap, Cover Assembly (Bottom)
	1113217	Left Side
	1113216	Right Side
29		Hinge (Bottom)
	1112919	Left Side
	1112923	Right Side
30	1112942	Shim, Hinge Bottom (4)
31	489237	Screw, 1/4-28 x 3/4
32	1112830	Grille Base, Top
33	1113150	Grille Base, Bottom
34	1113260	Grille Base, Front
35	489238	Screw (6)
36	1112835	Cover, Rear
37	1113123	Grommet, Wiring
38	1113079	Grommet, Flexible
39	1112926	Grommet, Tube
40	488248	Screw, 8 x 3/4 (2)

CABINET TRIMS AND BREAKER TRIM PARTS

For Model: 4KSRF36DTX1



1	1112665	Breaker Trim & Retainer Assembly
5	1112682	Magnet, Side (4)
6	1112683	Magnet, Freezer (2)
7	1112679	Magnet, Refrigerator (2)
8	1112710	Heater, Mullion
9	1112792	Trim (R.S.)
10	1112790	Trim (L.S.)
11	487432	Screw, 8-32 x 1/2 (12)
	489265	Screw (Repair)
12	1112800	Trim (Bottom)
13	488649	Screw, 8-32 x 1/2 (8)
14	1113304	Spacer Trim, Grille
15	1113604	Retainer, Unit Base (2)
16	487944	Washer (2)

REFRIGERATOR LINER PARTS

For Model: 4KSRF36DTX1



1		LINER (Not A Serviceable Part)
2	1112591	Spacer, Control Panel (3)
3	843436	Grommet, Screw (3)
4	842339	Grommet
5	1112115	Ladder, Shelf (2)
6	520965	Screw Support, Ladder (8)
7	488357	Screw, 8 x 1-1/4 (8)
8	486194	Screw, 8 x 1/2
	488908	Screw (Repair)
9	1112257	Hole Plug
10	1112126	Cover, Liner Back
11	1112219	Control Panel Assembly (Meat)
12	1112133	Insulation, Liner Back Cover
13	1112132	Duct, Meat Pan
14	1112218	Damper Control, Meat Pan
15	1112258	Control Knob, Meat Pan
16	837444	Retainer, Knob
17	1112789	Bracket, Light
18	1112613	Socket, Light
19	547225	Light Bulb
20	1112993	Wiring Harness, Air Baffle
21	1112709	Wiring Harness, Light Socket
22	1116793	Cover, Thermistor
23	1116959	Thermistor
24	1113078	Flexible Grommet
25	1112788	Shield, Light

FREEZER LINER PARTS

For Model: 4KSRF36DTX1



1		Liner (Not A Serviceable Part)
2	1112272	Ladder, Shelf (2)
3	1112271	Spacer, Ladder (4)
4	489193	Screw (4)
5	521516	Stud, Shelf (4)
6	538533	Support Clip, Icemaker (2)
7	538532	Grommet, Screw (2)
8	488552	Screw, 10-12 x 3/8 (2)
9	992720	Stud, Support (4)
10	836374	Stud, Retainer (4)
11		Rail, Evaporator Cover
	1112841	Left Side
	1112842	Right Side
12	486194	Screw, 8 x 1/2
	488908	Screw (Repair)
13	1112591	Spacer, Control Panel (3)
14	842534	Clip, Air Duct (4)
15	842339	Grommet (15)
16	1112260	Support, Evaporator
17	658944	Stud, Shelf (8)
18	487559	Screw, 8-15 x 1-1/4 (8)
19	1112843	Gasket, Evaporator Cover (2)

ICE CONTAINER PARTS

For Model: 4KSRF36DTX1



1		Spacer, Track
	1112282	Left Side
	1112281	Right Side
2	1112638	Roller
3	1112639	Eyelet, Roller
4	489212	Screw, 10-16 x 5/8
5	1113169	Stop, Roller
6	488307	Washer
7	486194	Screw, 8 x 1/2
	488908	Screw (Repair)
8	1112291	Bracket, Motor
9	851152	Motor Assembly
10	488906	Screw, 8-32 x 5/16
11	983663	Coupling, Motor
12	1112613	Socket, Light
13	1113128	Cover, Motor
14	487294	Screw, 8-32 x 3/8
15	1112285	Ice Container
16	1112378	Conveyor
17	983668	Coupling, Conveyor
18	946192	Drive Bar, Drum
19	946195	Bearing Nut
20	946193	Drum
21	946194	Baffle
22	1112385	Overlay, Cover
23	1112380	Front Cover
24	488886	Screw, 8-18 x 1/2 (5)
25	489211	Screw, 10-16 x 3/4
26	1112582	Baffle, Ice Container
27	489189	Screw, 8-15 x 1/2
28	1113138	Lens, Dispenser
29	547225	Light Bulb

REFRIGERATOR CONTROL PANEL PARTS

For Model: 4KSRF36DTX1



1	1112640	Control Panel
2	1113378	Inlay, Control Panel
3	1113226	Circuit Board
4	1116853	Control Knob
5	837444	Retainer, Knob
6	549702	Switch, Rocker Arm
7	1113133	Seal, Control Panel
8	489260	Screw (3)
9	534927	Hole Plug (3)
10	1112655	Shield, Control Panel
11	1112613	Socket, Light (2)
12	547225	Light Bulb (2)
13	486194	Screw, 8 x 1/2
	488908	Screw (Repair)
14	1112660	Lens
15	1112708	Channel, Wiring
16	1115375	Clip, Wiring (2)

FREEZER CONTROL PANEL PARTS

For Model: 4KSRF36DTX1



1	1112595	Control Panel
2	1112600	Inlay, Control Panel
3	1113160	Thermostat & Barrier Assembly
4	488974	Screw (2)
5	851387	Switch, Rocker Arm (Dispenser Motor)
6	1113132	Seal, Control Panel
7	1112615	Lens
8	489260	Screw (3)
9	534927	Hole Plug (3)
10	1112610	Shield, Control Panel
11	1112613	Socket, Light
12	486194	Screw, 8 x 1/2
	488908	Screw (Repair)
13	547225	Light Bulb
14	1112707	Channel, Wiring
15	549702	Switch, Rocker Arm (Light)
16	1112592	Knob, Thermostat
17	1115375	Clip, Wiring

REFRIGERATOR SHELF PARTS

For Model: 4KSRF36DTX1



1	1112244	Side Arm, Cantilever Shelf
2	1112155	Glass, Shelf
3	1112160	Reflector, Shelf
4	1112598	Gasket, Glass (2)
5	1112170	Trim, Shelf Front
6	489210	Screw, 6-32 x 1/2
7	1124006	Frame & Housing, Meat Pan
8	1112324	Retainer, Glass
9	1112245	Cover, Crisper
10	1112250	Glass, Crisper
12	1112262	Reflector, Glass
13	1112633	Gasket, Crisper
14	1112220	Crisper Pan
15	1112638	Roller
16	1112639	Eyelet, Roller
17	489211	Screw, 10-16 x 3/4
	489261	Screw (Repair)
18	488307	Washer
19	1113240	Utility Pan
20	1112195	Meat Pan
21	1113286	Spacer, Shelf
23	1107384	Egg Container, Bottom
24	1107388	Egg Container, Top
25	1112165	Crisper Spacer, Right Side (2)
26	489212	Screw, 10-16 x 5/8
	489261	Screw (Repair)
27	1113169	Stop, Roller
28	1112141	Crisper Spacer, Left Side (2)
29	486194	Screw, 8 x 1/2
	488908	Screw (Repair)

FREEZER SHELF PARTS

For Model: 4KSRF36DTX1



1	1112365	Solid Shelf
2	1112393	Front, Ice Compartment
3	1112340	Shelf, Fixed (2)
4	1112348	Reflector, Shelf
5	1112354	Trim, Shelf
6	489210	Screw, 6-32 x 1/2
7	1112360	Shelf, Cantilever
8	1112345	Reflector, Shelf
9	1112350	Trim, Shelf
10	1112305	Basket (Large)
11	1112310	Side, Basket (Left Side)
12	1112311	Side, Basket (Right Side)
13	1112315	Front, Basket
14	1112320	Overlay, Front
15	1112638	Roller
16	1112639	Eyelet, Roller
17	489211	Screw, 10-16 x 3/4
	489261	Screw (Repair)
18	488307	Washer
19	1112335	Basket (Small)
20	1112312	Side, Basket (Left Side)
21	1112313	Side, Basket (Right Side)
22	1112296	Basket Spacer, Right Side (2)
23	489212	Screw, 10-16 x 5/8
	489261	Screw (Repair)
24	1113169	Stop, Roller
25	486194	Screw, 8 x 1/2
	488908	Screw (Repair)
26	1112295	Basket Spacer, Left Side (2)
27	1113286	Spacer, Shelf

REFRIGERATOR DOOR PARTS

For Model: 4KSRF36DTX1



1	1112425	Door Panel, Refrigerator (Also Order Item 29)
2	939101	Screw Anchor (8)
3	1112945	Hinge Assembly, Top
4	1112940	Spacer
5	489282	Screw
6	1112921	Hinge Assembly, Bottom
7	1112533	Gasket Retainer, Side (2)
8	1112539	Gasket Retainer, Top & Bottom
9	1112546	Door Gasket, Magnetic
10	489101	Screw, 7 x 1/2 (36)
	488907	Screw (Repair)
11	1112508	Handle, Door
12	1112510	Insert, Door Handle
13	1107844	End Cap (Top)
14	1107849	End Cap (Bottom)
15	487052	Screw, 8-15 x 1/2
16	1112489	Trim (Top)
17	489112	Screw, 6-32 x 1/2
18	1112480	Trim (Side)
19	1112498	Trim (Bottom)
20	1112515	Panel, Interior Door
21	1112527	Ladder, Shelf (2)
22	1112530	Retainer, Shelf Ladder (2)
23	1112514	Back Up Plate (8)
24	486194	Screw, 8 x 1/2
	488908	Screw (Repair)
25	1112720	Bin, Utility
26	1112735	Door, Utility Bin
27	1112740	Door Shelf (4)
28	520747	Butter Tray
29	876029	Kit, Foam Slab (Required When Replacing Exterior Door Panel)

Following Parts Not Illustrated (Optional Parts Only)

4210545	Top Grille Trim Kit (8")
4210546	Top Grille Trim Kit (7-1/2")
4210464	Front Panel Kit (White)
4210469	Front Panel Kit (Black)
4210548	Front Panel Kit (Almond)
978849	Black Acrylic Static Cleaner

LITERATURE PARTS

LIT1113413	Use & Care Guide
LIT1113415	Energy Label
LIT1113417	Service & Wiring Sheet
LIT628107	Modular Icemaker Service Sheet
LIT4315802	Parts List

FREEZER DOOR PARTS

For Model: 4KSRF36DTX1



1	1112432	Exterior Door Panel, Freezer (Also Order Item 4)
2	1112997	Tube, Wiring
3	1112928	Retainer, Tube
4	876029	Kit, Foam Slab (Required When Replacing Exterior Door Panel)
5	1112977	Insulation, Dispenser
6	1112916	Hinge, Bottom
7	489282	Screw
8	1112944	Hinge, Top
9	1112940	Spacer Plate
10	537095	Clip, Expansion (2)
11	1112951	Wiring Harness, Freezer Door
12	1112533	Gasket Retainer, Side (2)
13	1112538	Gasket Retainer, Top & Bottom
14	1112545	Door Gasket, Magnetic
15	489101	Screw, 7 x 1/2 (34)
	488907	Screw (Repair)
16	1112508	Handle, Door
17	1112510	Insert, Handle
18	1107844	End Cap (Bottom)
19	1107849	End Cap (Top)
20	487052	Screw, 8-15 x 1/2
21	1112484	Trim (Top)
22	489112	Screw, 6-32 x 1/2
23	1112493	Trim (Bottom)
24	1112480	Trim (Side)
25	488320	Screw, 8 x 1/2 (2)
26	1112522	Panel, Interior Door
27	1113170	Overlay, Panel
28	1124003	Door Shelf, Outer Trim
29	1112770	Door Shelf, Inner Trim
31	1112763	Support, Trim Ends
32	227991	Wire Connector
33	939101	Screw Anchor
34	1112554	Ice Chute

DISPENSER AND FRONT PARTS

For Model: 4KSRF36DTX1



1	1107943	Housing, Dispenser
2	987049	Bracket, Water Fitting
3	987050	Water Fitting, Dispenser
4	487916	Screw, 8 x 3/8
5	987053	Water Tube
6	841707	Insert, Tube
7	488878	Clamp, Tube
8	488886	Screw, 8-18 x 1/2
9	488316	Screw, 8-18 x 3/4
10	987048	Grommet
11	938107	Heater, Ice Dispenser
12	938669	Ice Door Mechanism
13	983691	Gasket, Ice Door
14	987121	Shield, Impact
15	983690	Ice Door
16	489000	Screw, 9-12 x 1/2
17	1115309	Lever, Ice Dispenser
18	1115310	Pad, Lever
19	987917	Bearing, Clip
20	1115308	Lever, Water Dispenser
21	488307	Washer
22	983696	Spring, Lever
23	983697	Bearing, Lever
24	938665	Delay Mechanism
25	1107454	Bracket, Control
26	841336	Switch
27	984683	Insulation, Switch
28	488361	Screw, 4-40 x 1
29	987265	Lamp Holder
30	488500	Screw, 8-32 x 3/8
31	851386	Light Switch
32	1107457	Plunger, Extension
33	983986	Spring, Plunger
34	983987	Retainer, Pin
35	934302	Wiring Harness, Door
36	984494	Wiring Shield
37	1118269	Guiding, Ice
38	1119056	Glass Top
39	489197	Screw
40	487052	Screw, 8-15 x 1/2 (6)
41	851389	Light Bulb
42	1112888	Front Cover, Housing
43	1119000	Saddle, Lever
44	1112836	Cover, Dispenser Opening
45	1112837	Trim, Front (2)
46	487052	Screw, 8-15 x 1/2
47	983900	Grille, Overflow
48	934316	Switch
49	1113381	Overlay, Cover
50	489098	Union
51	487857	Nut-Ball Sleeve
52	488794	"O" Ring Seal
53	487944	Washer (2)
54	488568	Screw (2)
55	482672	Seal

UPPER UNIT PARTS

For Model: 4KSRF36DTX1



1	1113022	Assembly, Unit Base
2	1113386	Assembly, Sound Barrier
3	4318252	Compressor (Includes Items 8, 9, 10, 11, 12, 13, 21) (Also Order)
	876765	Tube Kit
4	1105220	Bracket, Mounting
5	1105219	Grommet, Bracket
6	1105200	Grommet, Mounting
7	489139	Screw
8	1113432	Overload (Production) (Includes Relay)
	1101000	Overload (Service) (Includes Relay)
9		Terminal Cover
	1105221	Production
	2154452	Service
10	1105222	Strap, Cover
11		Relay (See Overload)
12	1105212	Running Capacitor
13	1108065	Starting Capacitor
14	1108033	Clamp
15	487869	Screw, 8 x 3/8
16	1113015	Condenser
17	943447	Grommet (4)
18	1113019	Clamp (4)
19	487522	Screw, 8-32 x 5/8 (4)
20	1113228	Wire Tie (2)
21	1108023	Drier
22	1113083	Mounting Bracket, Motor
23	1113081	Motor, Fan
24	1113082	Blade, Fan
25	1113011	Orifice, Fan
26	1113303	Gasket, Orifice
27	488130	Nut (3)
28	489084	Screw, 8 x 1/2 (3)
29	486692	Speed Nut
30	1113225	Defrost Timer (10 Hour)
31	488911	Screw, 6-20 x 3/8
33	1113066	Clamp, Tube (2)
35	486194	Screw, 8 x 1/2
	488908	Screw (Repair)
36	1113075	Cover, Fan
37	1113027	Cover, Condenser
38	1113076	Extension, Housing
39	937360	Service Cord
41	1113162	Clamp, Cord (2)
42	1113229	Switch, Power Disconnect
43	488879	Screw, Ground
44	653035	Clip, Cord Plug
45	1112700	Wiring Harness, Unit Compartment
46	1113039	Stop

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")

876764 Valve, Access (3/16")

Production Compressor Requires Production Electrical Components. Service Compressor Requires Service Electrical Components. For Furth Information, Refer to Filmcard 19.1.

LOWER UNIT AND TUBE PARTS

For Model: 4KSRF36DTX1



1	1113405	Defrost Bi-Metal
2	1113043	Clamp, Bi-Metal
3	486194	Screw, 8 x 1/2
	488908	Screw (Repair)
4	1113293	Tube, Connect (Suction)
5	1113295	Tube, Connect (Discharge)
6	1113296	Tube, Flow Divider (2)
7	1113292	Valve, Fluid Control
8	1113294	Tube, Connect (Drier)
9	1113061	Heater, Drain Pan
10	1113062	Hanger, Heater
11	1113105	Bracket, Heater
12	487534	Screw, 8 x 1
13	1113256	Tube, Discharge
14	1113057	Sleeve
15	1113049	Heat Exchanger
16	1113040	Evaporator
17	1113408	Heater, Defrost
18	1113048	Clamp, Heater (2)
19	549419	Clamp, Heater (2)
20	1112844	Gasket, Evaporator
21	1112713	Clip, Connector
22	1113070	Guard, Hook-Up
23	851095	Strap (7)
24	488993	Clamp, Wiring
25	1113063	Drain Pan
26	1113064	Bracket, Drain Pan
27	1113065	Clip, Pan (2)
28	934011	Clip, Water Tube
29	1112702	Wiring Harness, Water Valve
30	1113384	Tube, Connect (Suction)
31	1113297	Tube (2)
32	1113096	Tube, Condenser Inlet

AIR FLOW AND RESERVOIR PARTS

For Model: 4KSRF36DTX1



1	945523	Fan Motor
2	992953	Compression Ring
3	992920	Fan Blade
4	548263	Bracket (Double)
5	938224	Bracket (Single)
6	548268	Grommet
7	486194	Screw, 8 x 1/2
	488908	Screw (Repair)
8	538449	Grommet, Screw
9	488500	Screw, Ground
10	942842	Terminal Block
11	1113271	Shield, Icemaker Plug
12	1112729	Channel, Wiring
13	1112703	Wiring Harness, Fan Motor
14	1111212	Scroll, Fan (Also Order Item 15)
15	1112976	Shield, Scroll
16	488772	Screw, 8 x 1/2
17	1112855	Assembly, Air Duct
18	1112868	Air Deflector, Icemaker
19	1112870	Cup, Motor
20	1112882	Shield
21	1112871	Fastener (3)
22	1112869	Gasket, Air Baffle
23	1112850	Cover, Air Outlet
24	488748	Screw, 8-32 x 1-1/2
25	1112275	Cover, Evaporator
26	1112565	Connector, Meat Pan Duct
27	487539	Screw, 8 x 1/2
28	1112840	Baffle, Evaporator
29	1112851	Diffuser, Air Duct
30	839912	Reservior, Water
31	1113158	Water Tube (Inlet)
32	841707	Insert, Tube
33	488819	"O" Ring Seal
34	488795	Compression Nut
35	1112875	Assembly, Air Baffle
36	1113147	Insulation, Air Diffuser
37	1113270	Shield, Side
38	1112878	Cover, Air Diffuser
39	489174	Screw, 8 x 2
40	488775	Screw
41	1112265	Tube, Meat Pan
42	1113272	Shield, Air Duct
43	1113159	Water Tube (Outlet)
44	488248	Screw, 8 x 3/4

ICEMAKER PARTS

For Model: 4KSRF36DTX1



1	489084	Screw, 8 x 1/2
2	1112845	Fitting, Water Tube
3	488878	Clamp, Tube
4	841707	Insert, Tube
5	488366	Clamp, Tube
6	836074	Dampener
7	1112556	Tube, Water
8	1106508	Seal Gasket
9	488645	Screw, 8 x 1/2 (2)
10	1113103	Valve, Solenoid
11	627018	Nut, Compression
12	227991	Connector, Wire
13	628170	Clip, Fuse
14	488292	Washer
15	1113106	Tube, Inlet Valve
16	510716	Clamp Tube
17	537588	Nut, Valve
18	627356	Cover
19	487294	Screw, 8-32 x 3/8 (2)
20	628189	Mold & Heater (Also Order)
	542638	Silicone Grease
21	627811	Motor
22	627791	Bearing & Inlet
23	627843	Ejector
24	627788	Ice Striper
25	627790	Support
26	627796	Retainer Thermostat (2)
27	627985	Thermostat (Also Order)
	542639	Cement Alumilastic
28	489258	Screw, 10-32 x 49/64
29	628135	Module Assembly
30	489276	Screw
31	627913	Shut Off Arm
32	1113403	Harness, Wiring
33	627915	Bracket
34	489128	Screw, 8-32 x 27/64
35	483042	Module Assembly (Includes Items 21, 25, 28, 29, 30 & 41)
36	1112847	Tube Clamp (4)
37	487415	Screw, 8 x 3/8
38	488794	"O" Ring
39	488819	"O" Ring
41	489136	Screw, (2) 3-24 x 3/8
43	486194	Screw, 8 x 1/2
44	1108005	Compression Nut

TOP GRILLE AND UNIT COVER PARTS

For Model: 4KSRF36DTX1



1	1113311	Panel Frame, Side (2)
2	1113312	Panel Frame, Top & Bottom
3	1113313	Back Up Panel
4	1113324	Bracket, Keyhole Mounting (2)
5	1113326	Shoulder Screw (4)
6	489232	Spring Washer (4)
7	486255	Nut (4)
8	489172	Nut (8)
9	1113422	Top Grille Assembly
10	1113085	Cover, Unit
11	486194	Screw, 8 x 1/2
	488908	Screw (Repair)
12	1113300	Cover, Component Assembly
13	1113317	Brace, Panel (2)